

ENDON®

Prisma Ceiling Pendant Fitting INSTRUCTION MANUAL

Safety Warnings

- This product is only suitable for connection to a 240V~50Hz supply in accordance with current IEE wiring regulations, and should be installed in accordance with local building regulations. It is for indoor use only, and is **not** suitable for a bathroom location.
- Before installing your light fitting always switch off the mains supply, and remove the appropriate fuse or switch off the appropriate circuit breaker before commencing installation. Ensure that no one else has access that would enable the supply to be inadvertently reconnected.
- **This is a Class 1 product and must be Earthed.** The terminal blocks are supplied according to requirements of the fitting.
- The LEDs in these products are non-replaceable.
- This product may contain delicate parts – be careful during handling and maintenance to avoid breakage.
- If you are in any doubt about your competence please consult a qualified electrician.
- If any modification is made it will invalidate the warranty and may render the product unsafe.

Care Information

Allow 10 minutes to cool before replacing, adjusting or cleaning.

Clean with a dry cloth only. Do not use liquid or abrasive cleaners on this product.

Assembly/ User Instructions

Before you start

Please read these instructions carefully before fitting and retain for reference. Check the packaging and make sure that you have all the required parts. Follow each assembly step in order to prevent incorrect assembly. Ensure that the product is fully assembled as illustrated before use.

Please note - This instruction covers multiple fitting styles. While the assembly steps are the same, your product may vary from the diagram.

The Light pack contains:



Light fitting
Terminal connection block(s)
Fixing pack

The following tools may be required:

Selection of cross and flat head screwdrivers.
Electric drill and assorted drill bits.
Wire strippers.
Electrical insulation tape

These assembly diagrams are intended as a guide – if in doubt consult a qualified electrician.

1. Decide on the position of the light fitting, or remove existing light fitting. Take a note of the position of the electrical connections. Ensure there is a solid mounting surface, preferably a wooden joist or joist bridge to support the weight of the light fitting.
2. Use the fixing bracket (1) as a template to mark the screw holes. Mark the screw holes and secure to the ceiling with appropriate screw fixings. Take care to avoid damaging any concealed wiring and pipes. Ensure the threaded posts (2) are correctly located in the fixing bracket before securing to the ceiling. This is to make sure the threaded posts are in the same position as the holes in the ceiling cup.
3. **Height Adjustment:** This will be easier to complete before attaching the product to the ceiling. To reduce the drop of this pendant, push the steel cable up into the ceiling cover. To increase the drop press button B. To reduce the length of the electrical flex, pull the flex through the cable grip C in the ceiling cover. Always ensure the weight of the product is supported by the steel cable and not the electrical flex.



Assembly/ User Instructions

- Support your fitting and connect the house wiring to the terminal block – see expanded wiring details below. Remove the terminal block box lid. Cover the box in 2 layers of good quality insulation tape. Connect the mains supply. Replace terminal block box lid. If you do not understand the connections you must consult an electrician.
- Slot the fitting over the threaded posts (2) and secure using the finials (3)..
- Turn on the power and test.

